

# **SPEED BY SPECTRE®**

*The 400mph Company™*

## **Intake Installation Instructions**

**P/N 905182(red filter) - P/N 905182B (blue filter)**

**P/N 905182K (black filter) - P/N 905182W (white filter)**

### **Year/Model**

**1973-87 Chevy Truck**

#### **Parts List**

1 - Heat Shield- Driver's Side	1 - DTM Plenum
1 - Bulb Seal- 26"	2 - Air Filters
1 - Bulb Seal- 30"	2 - 4" Double Flex 22° Boots
1 - Heat Shield- Pass Side	1 - 4" Coupler
1 - Bulb Seal- 26"	2 - Velocity Stacks
1 - Bulb Seal- 30"	8 - 4" Hose Clamps
1 - Intake Tube	1 - Air Cleaner Nut

#### **Step 1**

Install the Plenum on the carburetor with a low profile nut.

#### **Step 2**

Install the 2" long coupler with clamps, on the end of the Plenum inlet.

#### **Step 3**

Place the velocity stack adapter in the heatshields and install the flex coupler secondly making sure the flex boot is pushed completely against the heat shield. Once the adapter and flex boot are tight against the heatshield, fully tighten clamps. Install bulb seal around edges of the shields.

#### **Step 4**

Remove any components from the corners of engine bay and install heatshields using existing hardware (Most kits utilize factory body hardware).

#### **Step 5**

Place the tube in the flex boots and install into the coupler on the plenum secondly. Once everything is in place and lined up, fully tighten all clamps.

#### **Step 6**

Install filters onto the velocity stack adapters with the supplied clamps and fully tighten.

If you have any difficulties or questions regarding the installation of this intake system, contact the Spectre Performance Technical Department by email - [Tech@spectreperformance.com](mailto:Tech@spectreperformance.com) or by phone 1-909-673-9800 Monday thru Friday 6:00am to 2:00pm PST.