



INSTRUCTIONS INSTRUCCIONES

1. Thread the appropriate stud into carburetor and tighten in place with nut.
2. Add additional couplers and nuts as necessary to reach the desired height above air cleaner lid.
3. At the desired length secure couplers by tightening all nuts as shown.
4. Place air cleaner over stud and tighten in place with wing nut.

1. Enrosque el remache apropiado en el carburador y use la tuerca para que quede ajustado en su lugar.
2. Agregue acopladores y tuercas adicionales para obtener la altura apropiada para el filtro de aire.
3. Teniendo la altura apropiada, asegure los acopladores ajustando las tuercas.
4. Coloque el filtro sobre el remache y ajústelo con la tuerca de mariposa.

SPECTRE™

©2010 Spectre Performance