

## Installation Instructions

P/N 42753 (chrome) - P/N 42753G (bronze)

P/N 42753K (black) - P/N 42753S (silver)

### Step 1


Remove the factory brake fluid reservoir cap.

### Step 2

Place the rear of the cover onto the fluid reservoir and press down to engage the tabs onto the rear of the reservoir then press down on the front of the cover to engage the front tab onto the front of the reservoir.

**ATTENTION:** Do not use harsh chemicals to clean covers.

If you have any difficulties or questions regarding the installation of this part, contact the Spectre Performance Technical Department by email - [Tech@spectreperformance.com](mailto:Tech@spectreperformance.com) or by phone 1-909-673-9800 Monday thru Friday 6:00am to 2:00pm PST.

 **WARNING** This product can expose you to a chemical or chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.