

Installation Instructions

P/N 42829 (chrome) - P/N 42829G (bronze)

P/N 42829K (black) - P/N 42829S (silver)

Step 1

Clean the top of the factory coolant reservoir cap with rubbing alcohol to remove any dirt, oil or contaminants.

Step 2


Peel the backing film off the double sided tape, then place the cap cover onto the factory cap and press firmly to set.

Step 3

For all other Cap Covers, place the cap cover onto the factory cap and press firmly to install until the tabs engage fully around the stock cap.

ATTENTION: Do not use harsh chemicals to clean covers.

If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.

 **WARNING** This product can expose you to a chemical or chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.