



## Installation Instructions

P/N 42881 (chrome) - P/N 42881G (bronze)

P/N 42881K (black) - P/N 42881S (silver)

### **42837**

#### **Step 1**

Before you permanently install the fuse box cover, place it onto the factory fuse box lid to ensure proper fit and alignment.

#### **Step 2**

Then clean the top of the factory fuse box lid with rubbing alcohol to remove any dirt, oil or contaminants.

#### **Step 3**

Peel the backing film off the double sided tape. Place the lid onto the fuse box lid making sure it aligns properly and press firmly to set.

### **42829**

#### **Step 1**

Clean the top of the factory coolant reservoir cap with rubbing alcohol to remove any dirt, oil or contaminants.

#### **Step 2**

Peel the backing film off the double sided tape, then place the cap cover onto the factory cap and press firmly to set.

#### **Step 3**

For all other Cap Covers, place the cap cover onto the factory cap and press firmly to install until the tabs engage fully around the stock cap.

### **42831**

#### **Step 1**

Place one half of the handle cover on each side of the factory dipstick handle, then press firmly together until the cover clamps into place.

**ATTENTION:** Do not use harsh chemicals to clean covers.

If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.

 **WARNING** This product can expose you to a chemical or chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.