



Installation Instructions

P/N 42953 (chrome) - P/N 42953G (bronze)

P/N 42953K (black) - P/N 42953S (silver)

Step 1

Remove the factory brake fluid reservoir cap.

Step 2

Before you permanently install the brake reservoir cover, place it onto the factory brake reservoir to ensure proper fit and alignment.

Step 3

Then clean the top of the factory brake reservoir with rubbing alcohol to remove any dirt, oil or contaminants.

Step 4

Peel the backing film off the double sided tape. Place the lid onto the brake reservoir making sure it aligns properly and press firmly to set.

ATTENTION: Do not use harsh chemicals to clean covers.

If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.

