

Installation Instructions

P/N 42981 (chrome) - P/N 42981G (bronze)

P/N 42981K (black) - P/N 42981S (silver)

42927

Step 1

Before you permanently install the fuse box cover, place it onto the factory fuse box lid to ensure proper fit and alignment.

Step 2

Then clean the top of the factory fuse box lid with rubbing alcohol to remove any dirt, oil or contaminants.

Step 3

Peel the backing film off the double sided tape. Place the cover onto the fuse box lid making sure it aligns properly and press firmly to set.

42929

Step 1

Place the cap cover onto the factory cap and press firmly to install until the tabs engage fully around the stock cap.

42951

Step 1

Place one half of the handle cover on each side of the factory dipstick handle, then press firmly together until the cover clamps into place.

42953

Step 1

Remove the factory brake fluid reservoir cap.

Step 2

Before you permanently install the brake reservoir cover, place it onto the factory brake reservoir to ensure proper fit and alignment.

Step 3


Then clean the top of the factory brake reservoir with rubbing alcohol to remove any dirt, oil or contaminants.

Step 4

Peel the backing film off the double sided tape. Place the lid onto the brake reservoir making sure it aligns properly and press firmly to set.

ATTENTION: Do not use harsh chemicals to clean covers.

If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.

 **WARNING** This product can expose you to a chemical or chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.